
How to use your sensor(s) readings





REMEMBER your robot configuration:

Port 2 - Right colour sensor

Port 3 Left colour sensor

Port 4 - Ultrasonic Sensor

Port B - Left motor

Port C - Right Motor

